


RevNo	Revision note	Date	Signature	Checked

The directional and Centre-DN switches are mechanically tied to the potentiometer track. The value of the resistive track and the angles of activation for the switches are determined by the potentiometer specified for the joystick. For activation angles please consult the product brochure on page 6.



Itemref	Quantity	Title/Name, designation, material, dimension etc	Article No./Reference
Designed by Mark Dzidowski		Checked by Mark Dzidowski	Date 01/05/08
		Approved by - date RJD - 19/03/08	File name DW-0073
			Scale 1:1

<h2 style="color: #800080;">Control Devices</h2>		<h3 style="color: #800080;">JC6000 Pin Out Diagram</h3>	
		DW-0073	Edition 1 Sheet 1/1